


LEGEND:



ACM TX2, TX2 COLOR, TX4		DITEC/ENTREMATI BIXLP, GOL4, BIXLG, ZEN		NICE SMILO, FLOR-S, VERY-VR, FLOR-S ERA, ONE (ON), ON ERA, INTI, ERGO, PLANO, ONE (ON FM)		STAGNOLI KALLISTO, VENUS AV223	
ADYX TE4433H BLUE, 433-HG BRAVO		DOORHAN TRANSMITTER 4		NORMSTHAL RCU 2/4 K, EA 433 2/4 K		TAU 250K-SLIMRP, 250K-SLIMR, 250T-4RP	
AERF COMPACT, HY-DOM, MERCURI B, MERCURI C, SABUTON, MARS, SATURN, ST3/N, TERRA, TMP-1, TMP-2, UNITECH		DOORMATIC MILENY, MILENY-EVO		NORTON NEO, TXCD		TELCOMA FM400E, FM400	
ALLMATIC BROWN, BROWN RED, BRO.OVER, PASS, MINIPASS, TECH3, FOR4		ECOSTAR RSC, RSE, RSZ		NORTON GO NORTON, GO MINI NORTON		TOR LIFT TORMIT4	
APERIO GO, GO PRO, GO MINI		ERREKA IRIS, ROLLER 2, ROLLER 433, ROLLER 868, SOL433, SOL868, VEGA 433, VEGA 868		NOVOFERM MCHS, MICRO-NOVOTRON 502, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS, MINI NOVOTRON 522		V2 TSC, TXC, TRC, HANDY, PHOENIX, PHOX 433, PHOENIX 868, PHOX 868	
APERTO (Sommer) 4020-TX03-434, TX02-434-2, TX02-868-2		FAAC TML 433SLH, DL 868 SLH, XT 868 SLH, XT 433 SLH, T 868 SLH, T 433 SLH, XT 868 SLH BLACK, XT 433 SLH BLACK		O&O TX, T.COM R4-2, T.COM R8-2, TWIN, TX (NEO)		VDS ECO-R, TRQ P	
APRIMATIC TR, TM4, TXM		FAAC XT 433 RC, TE433HG, XT4 433 RCBE		PRASTEL MTE, MPSTLE, MPSTP2E, TCE, BFOR, TRQ-P, SLIM-E			
AVIDSEN 104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250, TX4 114253		FADINI JUBI-SMALL, JUBI 433, DIVO 71/4		PUJOL TWIN, VARIO, VARIO MARS, VARIO OCEAN, NEO			
BALLAN FM400, FM400E		GENIUS AMIGO JA332-JA334 868, AMIGOLD 868, KILO 433 JLC, KILO 868 JLC		RIB LITHIO			
BENINCA TO. GO, WV, TWV, ROLLKEY, APPLE, LOT WCV, CUPIDO, TO.GO. QV, HAPPY VA		GENIUS BRAVO, ECHO		ROPER NEO			
BENINCA IO, TO.GO. VA		GIBIDI AU1600, AU1600 WOOD, AU1680, AU1680 WOOD, DOMINO, MAKO		ROPER GO ROPER, GO MINI ROPER			
BFT MITTO, MITTO M, MITTO RCB, MITTO A, TRC, GHIBLI, MURALE, KLEIO		JCM NEO, TWIN		SABUTOM BROOVER, BROSTAR			
CARDIN TRQ 5449, TRQ 5449 GREEN (PRECODE), TXQ 5449, TXQ 5449 GREEN, TRQ 5486, TXQ 5486, 5437 TX, XRADO		JCM GO, GO PORTIS, GO NORTON, GO MINI		SEAV BE HAPPY RS, BE SMART			
CASALI GENIUS/CASALI A252RC		KBLUE ETH-TEL01		SECULUX NEO			
CHAMBERLAIN/LIFT MASTER/MOTOR LIFT 953ESTD, 371 LM, 971LM, 84330E, 94334CE, 94333E/94334E/94335E, 9747E, 1A5639-7, 1A5477, 1A6487, 13282372, 94330EM-L/9333EML/94335EML, 84330EML/84333EM-L/84335EML, 8747EML		KEY 900TXB-42R, TXB 44R, SUB 44R		SILVELOX Mhz 2007, QUARZ SAW			
CLEMSA MUTANCODE, T, T-8, E-CODE N		KING GATES CLIPPER, STYLO		SIMINOR CVXNL, MITTO			
CLEMSA Attenzione! Codice Fisso MASTERCOD MV		KLING KUA, KUA E, KUA S		SIMINOR SIM433			
DASPI ZERO RC		LABEL SPYCO		SOMFY K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA			
DEA SYSTEM PUNTO 278, GOLDR, GENIE R 273, GENIE R-GT2M, MIO TR, GT2M, TRN		LIFE FIDO		SOMMER 4010, 4011, 4014 TX03-434-2, 4013 TX03-434-4, 4020 TX03-868-4, 4026 TX03-868-2, 4022 TX02-434-2, 4025 TX02-868-2, 4031 TX08-868-4			

D.O.R. TECHNOLOGY

Close to the automation and before using the original remote control, press and hold pressed the button on the WHY EVO remote control until the LED starts to flash. Wait for the end of the flashing.

ACT ON THE RECEIVER

Close to the automation and before using the original remote control, press and hold pressed the PRG or PGM button in the receiver; then press the button of WHY EVO remote control.

DIRECT FUNCTIONING

Close to the automation and before using the original remote control, press the button of WHY EVO remote control for 4/5 times.